{§CavitySliders®

Single Cavity Slider with SmartMount **Installation Instructions**

§MidWay® **\$Ultimate® §**SoundStop®* §TimberFormed® §EasyOpen® WC §AluSealed® **§**SofStop® * Extra data sheets are required for these units.

Before you Start

Wall construction

The wall referred to in these instructions is ex 100mm x 50mm wooden framework. In reality this may mean a 94mm x 47mm, 90mm x 45mm or 140 x 45mm (Ultimate®) wooden framework. Although not shown, the unit may also be fitted into other types of wall materials (steel, concrete, brick, etc.). For concrete or masonry walls, fix a 100mm x 50mm timber jack stud into the opening on each side. Fix these in place with ø10mm x 98mm long countersunk masonry anchors at 400mm centres.

The lintel should be straight and level.

The jack studs should be straight and plumb to the lintel.

Lintel/trimmer sizes.

CS Cavity Sliders are non-loadbearing. The lintel (or trimmer, ceiling joist or other structural component) directly above the track must span the full trim size opening width. Timber lintels sized from NZS3604 (NZ) / AS1684 (AU) are acceptable if the weight of the door is less than 75kg/m width of door. If heavier, specific design is required. Please consult your engineer.

Trim size (hole in the wall framing):


Height: door leaf height + 95mm (All units including SofStop)

Width: $(door width \times 2) + 30mm$

Width: (door width x 2) - 70mm (EasyOpen only)

Standard under door clearance.

With the unit sitting hard on top of the concrete or timber floor, the clearance under the door leaf ranges between 25-32mm (adjustable). The majority of this clearance is taken up by the floor covering (carpet, tiles etc.).



Modified under door clearance.

If you require more than 32mm clearance under the door, pack the cavity unit off the floor by the amount you need.

If you need less than 25mm clearance (e.g. polished timber floors) there are two options:

- a) CS can supply seals which fit to the bottom of the door.
- b) The unit can be made up to 15mm shorter (at time of order).

Above door clearance.

Standard clearance above the door is 9-15mm.

If you require 3-9mm clearance above the door, this must be requested at time of order. The SmartMount plates must be rebated into the top of the door.

Contamination of the top track.

Never drill, nail or screw through the centre section of the track. The track running surface must be clean and free of any contamination or damage, e.g paint or dust. The wheels on the carriage should not be chipped, dented or have swarf embedded in the tyre. Take extra care with the carriages to avoid any damage during the installation process.

Fixing cavity slider to the floor

Installing the cavity slider 100% plumb and level will NOT quarantee a correctly sliding door. If the wall, lintel, floor and door are not all plumb, level and straight, the door may slide incorrectly into the pocket. For this reason, the skirting block fixing (at the base of the pocket frame behind the split jambs) should only be secured once you have ensured the door is running parallel to the cavity pocket.

Remove packaging and check components.

Position the cavity unit so the aluminium back stud is parallel with the floor and remove the transport support cleat (if fitted) from the bottom plate assembly.

Check for any transportation

If anything looks damaged or out of specification or you are unsure, contact CS before beginning your install.


Preparation

1. Fit the Track (if not yet fitted).

Check inside the track and clean out all dust and debris. Remove temporary frame packers.

Slide the track into the unit and fix to the aluminium split jambs, back stud and intermediate studs (if fitted).

Make sure that the track holes line up with the split jamb and intermediate stud screw tubes.



2. Prepare Door (if not yet fitted).

a) Bottom of door: Cut a groove to the dimensions and tolerance shown. Make it central to the door thickness

Fit track to unit

5-5.5 20-21 and absolutely straight.

b) Top of the door:

Prepare SmartMount plate holes to the size and depth as shown. Make sure they are placed exactly in the centre of the door thickness.

Do not over-machine the holes.

*NoClosingJamb: Front mounting plate needs to be set back further. Refer to additional instructions.


c) Front edge of the door:

Drill a Ø11mm access hole as shown. Make sure it is exactly in the centre of the door thickness, runs straight

and meets the mounting plate hole. A drilling guide is available if

Access hole Drilling _

d) Fix the SmartMount plates to the doors using the screws supplied.



e) Attach carriages.

Line the rear carriage hanger pin up with the hole in the SmartMount plate. The magnet will draw the pin into the correct position and it will click into place. Repeat for front carriage.

f) Lock front SmartMount plate.

Split jamb screw tubes

Insert a screwdriver into the access hole and turn the locking pin 90 degrees clockwise until vou hear a click. Check that the carriage is locked in place.

Insert the cover plug to cover the access hole.

3. Fit Door (if not already fitted) A, B or C).

A Standard (non-SofStop) Slide the door into the track.

SofStop® Single (Soft Close)

Check hanger pins.

Depending on the unit you have purchased, you may need to replace the hanger pin that connects the carriage to the SmartMount plate.

SmartMount with SofStop and 9-15mm Clearance


SmartMount hanger Red pins are supplied space with a red spacer 36 to prevent it being wound up too far and interfering with the SofStop activator in the track.

SmartMount with SofStop and 3-9mm Clearance

Replace the hanger pin on the front carriage with the short (31mm) pin supplied in the SofPack. Attach the carriages to the

31

SmartMount plates. Attach SofStop cassette to front carriage with M5 pan head machine screw. Tighten with #2 Phillips screwdriver.



C & SofStop® Twin (Soft Open & Close)


DO NOT LINE THE POCKET UNTIL THE SOFSTOP MECHANISM HAS BEEN INSTALLED AND TESTED.

Slide rear activator to middle of pocket before fitting door.



Continue with instruction 3B to fit

4. Fit closing jamb (if supplied).



#6 x 31mm


flat head

screws

AluSealed units: Ensure the closing jamb plate is fitted to the top of the closing jamb as Stop shown with the stop lug towards the cavity pocket.

Installation

5. Place unit into framed **opening.** Plumb up the two split jambs. Use a level!




6. Fix aluminium back stud.

While keeping the timber split jambs plumb, pack behind the aluminium back stud.

Screw the aluminium back stud including the packing to the jack stud through the pre-punched holes. To timber jack stud: #8 x 29mm

wood screws (not supplied) To steel jack stud: #8 x 29mm self-

tapping screws (not supplied)



7. Level the track.


The track must be fitted level and straight. Pack above the track where necessary.

Doors under 910mm wide: do not fix the track to the lintel.

Doors over 910mm wide:

Removable Head Jamb: Fix the track to the lintel at 600mm centres through the aluminium flanges on both sides of the track. Fit the first screws 50mm back from the closing jamb end of the track.

Counter bore the timber pelmet blocks so that the screw heads pull hard up under the aluminium flanges.



Screws for:

Timber lintel: #8 screws to penetrate lintel by at least 25mm (not supplied) Light steel lintel (under 2mm): #8 self-tapping screws to penetrate lintel by at least 5mm (not supplied) Heavy steel lintel: M5 machine screws (not supplied)


Fixed Head Jamb: The head jamb does not need to be removed at a later date for access. Screw holes can be filled and painted over.

8. Fix the closing jamb.

Plumb closing jamb. Use a level! Pack and nail at 500mm centres to the jack stud through the recessed centre section of the closing jamb. Fix the top of the closing jamb first, then the bottom of the closing jamb. Ensure that the distance between the closing jamb and the split jamb are the same, both at the bottom and top.

The distance at the bottom must never be more than the distance at the top. Measure this carefully!

Fix between the top and bottom. Use a level to make sure that the closing jamb is straight and plumb in both directions.




AluSealed units: Screw through pre-drilled holes in the centre of the closing jamb.

Aluminium plugs are supplied to cover the fixing holes. Put these in <u>only</u> when you are satisfied with the complete installation!

9. Fix bottom plate assembly.


The door must slide parallel with the bottom plate assembly. If not, gently tap the front of the bottom plate to the left or right until it does.

The door should now slide smoothly and fit into the recess in the closing jamb, with parallel gaps on either side between the door and the closing jamb.



Fix the bottom plate assembly to the floor: To **concrete** floors:


Use ø8mm x 90mm masonry anchors through the pre-drilled holes in the skirting fixing blocks of the bottom plate.



(See red stamped arrow on the timber). To **timber** floors: Use Ø3.15mm x 75mm nails on either side in the centre of the skirting fixing block thickness. (See the red stamped ⊕ on the timber). Pre-drill Ø3mm holes for these nails.

10. Adjust the door.

Use the spanner supplied to adjust the door for height and plumb.



Note: The top of the hanger pin screws into a self-locking Nyloc type nut in the carriage. For the assembly to remain in its adjusted position over time the hanger pin must be screwed into the nylon locking portion of the nut by at least 3 full turns.


§SofStop® Single & Twin

11. Set front activator position.


Note: Single Soft Close requires one front activator only.

Twin Soft Open & Close requires two activators. One of them should already be in the track above the pocket (Step 3).

 a) Open the door and insert the front activator, moving it into the approximate centre of the door opening. Tighten 2 grub screws.




 Gently close the door until the pickup mechanism goes past the activator. You will hear a click.



- c) Open the door again and loosen the activator grub screws. The cassette is now charged.
- d) Position the distance setting tool (jamb spreader) against the centre of the closing jamb or finished wall and gently close the door onto it.

The activator will slide along the track into the correct position.



 e) Without moving the activator, open the door and securely tighten all four grub screws.

WARNING: If the door soft closes, but does not come to a stand still on the closing jamb or track stop, you risk breaking the hook on the soft close mechanism.

If you use the distance setting tool correctly this will be avoided.

SofStop® Twin Only


12. Set rear activator position.

 a) Close the door and move the rear activator into the approximate centre of the pocket.

Do not tighten grub screws.

b) Position the distance setting tool inside the back stud and gently open the door onto it.

The activator will slide along the track into the correct position.



The rear activator is now positioned. Securely tighten all four grub screws.


Note: Twin SofStop cannot be adjusted after installation of wall linings.

Finishing

13. Fit the head jambs (if required).

a) Fixed Head Jamb:


Head jamb is already in place and does not require fitting.



b) Removable Head Jamb Option:

Before fitting head jambs, adjust the door for plumb and for the desired clearance under the door (**Step 10**).


Slide the head jamb into place between the vertical jambs. Flush up the joints, then screw into place. Gently tap wooden plugs to cover the screw heads.



c) AluSealed Head Jamb Option:

Screw in place through both ends at the top of the head jambs.

AluSealed head jambs longer than 1 metre require an extra screw to hold the centre of the jamb to the bottom of the track as shown.



Spot through the pre drilled hole in the flange with a Ø2.5mm drill into the bottom of the track.

Ensure track running surface is not damaged:



Hole must not be larger than ø2.5mm.

After installation but before lining, clean the full length of the inside running surface of the track with a soft rag.

TAPE UP THE TRACK to ensure no dust or debris enter the track or SofStop mechanism during building works.

Warranty does not cover damage arising from paint or debris in the track, wheels or mechanism.

14. Fixing the wall linings.


NB: If installing Twin SofStop, **DO NOT** line the pocket until the
SofStop mechanism has been installed
and tested.

The cavity slider comes with the split jambs intentionally 'rounded out' to accommodate any slight bowing of the door leaf and to allow door hardware to clear the jambs.

The standard clearance is 5-7mm between door and split jamb using a 38mm door

The supplied 'jamb spreader' should be inserted into the cavity slider opening prior to fixing wall linings and architraves.

CS Ultimate: use wedges to maintain clearance.



Wherever possible, linings should only be glued on.

Use short drywall screws to hold linings in place until glue is dry.

10mm linings: use **maximum 25mm** long drywall screws.

13mm linings: use **maximum 28mm** long drywall screws.


Sealing the inside of plasterboard linings and MDF architraves is recommended.

AluSealed: When fixing wall linings above the head jambs do not allow the linings to finish lower than 5mm below the top of the head jamb.

15. Fitting architraves.

Nail the architraves to the four vertical jambs and the two horizontal head jambs.

Use panel pins with a maximum length of 25mm plus the thickness of the architrave.




Nail the back of the architrave to the split jamb blocks using panel pins with a maximum length of the combined thickness of the architrave and wall linings plus 15mm.

Note (for removable head jambs): Nail the horizontal architraves to the head jambs but **do not** nail them to the timber pelmet blocks above the head jamb.


16. Fitting skirting.

Make sure that you do not puncture the aluminium extrusion of the bottom plate assembly. Use panel pins to fix the skirting to the fixing block.

Do not hammer too hard against the bottom plate. This may damage the channel where the door slides.



17. Insert the track notch cover if required.



18. Removing the Door

a) Removable Head Jamb

existing paint work.

Begin by removing the architrave and head jamb from one side (if fitted).


Make a thin knife cut where any paint joins two components so as not to tear

b) SmartMount/ Fixed Jamb Option:

If your head jamb is fixed it does not need to be removed for access.

Use a screwdriver to turn the locking screw anti-clockwise one quarter turn and unlock the hanger pin.

Use the supplied spanner to slide the hanger pin sideways.



The whole carriage (including the hanger pin) will now disengage from the SmartMount plate.

It is not always easy to slide the spanner sideways. You may need to relieve the door's weight by using a pump wedge or putting a wedge between door and floor.




If you have trouble removing the door from the pocket: lift the unlocking clip and slide the black nylon T-guide backwards slightly.

If you need to remove the T-guide: lift the unlocking clip and pull the black nylon T-guide forward.

Use a hook to aid removal if required.

To remove the carriages: Slide them out of the notched end of the track.



Cavity Sliders Auckland Head Office

5 - 7 Rakino Way, Mt Wellington 1060

T +64 9 276 0800

E info@csfordoors.co.nz
W www.cavitysliders.co.nz





© All copyright and other property in this document is reserved by Cavity Sliders Limited. Details and specifications are subject to change without notice. Whilst all care is taken to ensure the accuracy of all information, no responsibility will be accepted for any errors or omissions. Drawings are not to scale. *Guarantee conditions apply. Contact Cavity Sliders for details. CS CAVITY SLIDERS® (O.D. 1986). NZ Patent No: 533838.